
CHAPTER 2

TECHNICAL ADMINISTRATION

Technical administration is basically the filling out of paperwork required to complete a task. Whether the task is maintenance or repair in nature, it is not fully completed until all documenting paperwork has been finalized. You, as the technician, are responsible for ensuring that all paperwork is completed for each task you are assigned.



THE MAINTENANCE DATA SYSTEM (MDS)

The Maintenance Data System (MDS) provides a means of recording maintenance actions in substantial detail. This allows a variety of information concerning these actions and the performance of equipment involved to be retrieved. (In older documents, you may see the system refereed to as MDCS.) One of the major objectives of the MDS is to provide the capability of reporting configuration changes. In the following paragraphs, we will describe MDS subsystems that you will use frequently.

MAINTENANCE DATA SYSTEM (MDS) FORMS

In the following paragraphs we will briefly discuss the MDS forms that you as an ET are most likely to come across in your daily routine. For more in-depth information on the MDS forms, we recommend that you read chapter 9 of OPNAVINST 4790.4, *Ships' Maintenance and Material Management (3-M) Manual.* Because the supply forms associated with the

MDS have been discussed in other training manuals, we will not cover them here.

Ship's Maintenance Action Form-OPNAV 4790/2K

This form, shown in figure 2-1, is the primary maintenance form. It is used by maintenance personnel to report (1) deferred maintenance actions and (2) all completed maintenance actions (including previously deferred actions).

The OPNAV 47902K contains six sections that require entries, depending on the type of maintenance action being reported. The form is printed on paper that does not require carbon to make multiple copies. Whenever you make an entry on this form, print the information, using all CAPITAL letters. Be sure the information is legible and inserted within the "tic" marks. If you make an error, line it out using a single line and enter the correct information.

Supplemental Form-OPNAV 4790/2L

This form, illustrated in figure 2-2, is used to provide amplifying information for a maintenance action reported on a 2K form. For example, you may include on the 2L information from drawings, listings, associated parts placement, part labels, and the like, for use by a repair activity.

When you need to use an OPNAV 4790/2L with an OPNAV 4790/2K, enter in block 35 of the 2K the notation "2L USED."

Maintenance Planning and Estimating Form-OPNAV 4790/2P

This form is used with an OPNAV 4790/2K that defers maintenance to be done by an IMA under the Intermediate Maintenance Management System (IMMS). It provides information necessary to allow screening and planning to be done in detail.

Figure 2-3 illustrates this form as it may appear when planning and scheduling have been completed by a repair activity. Chapter 12 of OPNAVINST 4790.4B contains detailed information on the use of the form.




Figure 2-1.—OPNAV 4790/2K, Ship's Maintenance Action Form.

NAV 4790/2L /Rev 4-73/ S/# 0107-LF-770-3040	SUPPLEMENTAL F	Arren (8, Primer)		-
CTION I. IDENTIFICATION		3800	CONTROL NUMBER	
SHIP'S NAME	8 HULL NUMBER	C SHIP'S UIC 0	WORK CENTER E JOSEO N	~ 0
			<u> </u>	
		CONTINUATION FOR	2K 2L	
CTION II. REMARKS/SKETCHES				
ECTION III. AUTHENTICATION				===
FIRST CONTACT/MAINTENANCE MAN /Prut)	I DATE J. S	ECOND CONTACT/SUPERVISOR (Print)	K DATE	
	1		,	

Figure 2-2.—OPNAV 4790/2L Supplemental Form.

OPNAV 4790/2P (6-84) M	AINTENANCE PLANNING & ESTIMAT	ING FORM (P & E)	
SECTION I. PLANNING		D8 C0	NTROL NUMBER
A SHIPS NAME	B. HULL NUMBER	1 SHIP'S UIC 2 W	ORK CENTER 3 JOS SEG NO
USS WHITE PLAIN	VS AFB4	\$ 5,8,3,5 E	E \$ 1 1 6 \$
4. PERIODIC MAINTENANCE REQUIREMENT	5 PERIODICITY 6. YYMM		1-19111000
8. SCREENING ACTION	8 QUALITY ASSURANCE REQUIREMENTS		10 SPECIAL REQUIREMENTS
a. DEPOT ACCOMPLISH	SUB SAFE	S SPECIAL CLEANING	. Ø 3 KEY EVENT
b. X : X IMA ACCOMPLISH	b. LEVEL I	h. SPECIAL TESTING	b. PECIAL INTEREST
c i TSU/NAVSEC/NOSSO/ETC	c. NUCLEAR LEVEL I	SPECIAL IDENTIFICATION	C DRY DOCK REQUIRED
d h SHIPS FORCE (IMA) (DEPOT) ASSIST	d NON DESTRUCT TEST	i NOISE CRITICAL	PRE OVERHAUL TEST REQUIRED
SHIP TO SHOP	NUCLEAR WORK PROCEDURES SUBMARINE ANTENNA	RADIOLOGICAL	POST OVERHAUL TEST REQUIRED DEPARTURE TEST
1 ACCOMPLISH WITH MODIFICATIONS	ENGINEERING DIVISION	OTHER CONTROLS	1. REQUIRED
C IUC SIGNATURE	D TYCOM SIGNATURE		11 NORMALLY DONE BY
			S/F b IMA c DEFOR
SECTION II. SCHEDULING			
	السيني ماييدها	KEY OP 17 TASK	
IS ASST WORK CENTER IS SCHED START DATE TO SCHE	D COMP DATE 21 EST MHRS 22	KEY OP 23 TASK	
5 1 A 6 2 4 7 6 2		KEY OP 29 TASK	
5 2 A 6 2 4 5 6	2 5 9 0 1 0 0 D COMP DATE 33 EST MINRS 34	KEY OP 35 TASK	1 1 1 1 1 1
VA OA	DA EST MINS	KEY OP 36 TASK	
38 ASST WORK CENTER 37 SCHED START DATE 38 SCHE	D COMP DATE 39 EST MHRS 40	KEY OF 41 TASK	*************************************
42 ASST WORK CENTER 43 SCHED START DATE ME SCHE	D COMP DATE 65 EST. MHRS 46	KEY OP 47 YASK	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
		<u></u>	
SECTION III. TECHNICAL DOCUMENTATION			ON BOARD YES NO
		-111111	
	 	 	
SECTION IV. IUC/REPAIR ACTIVITY/TYCOM RE			
	REPAILRS	T.O. 60	, \$, R,OV
M,A,T,E,R,I,A,L			
		 	
		· · · · · · · · · · · · · · · · · · ·	
			1 1 1 1 1
		<u> </u>	
SECTION V. SUPPLEMENTAL PLANNING			
BO EST MANDAYS ST EST MANDAYS COST 8	52 EST, MATERIAL COSTS	SO EST TOTAL COST 8	54
S/N 0107-UF - 770-3079	_ <u> </u>		
5 . 3 to 10 . 10 . 30 . 3			

Figure 2-3.—OPNAV 4790/2P, Maintenance Planning and Estimating Form.




Figure 2-4.—OPNAV 4790/2Q, Automated Ship's Maintenance Action Form

Automated Ship's Maintenance Action Form-OPNAV 4790/2Q

This form, shown in figure 2-4, is basically the same as the 4790/2K, except that it is filled in by computer. It contains the same information as the 2K. You may enter

additional information by hand as necessary. You may also use this form as an automated work request and in preparation for INSURV.

NOTE: Data entered into the computer is checked for accuracy and completeness. Elements that contain

errors are brought to the attention of the operator for correction as required by OPNAVINST 4790.4.

Automated Work Request (AWR)-OPNAV 4790/2R

This form is produced by the computer and combines the basic information submitted on the OPNAV 4790/2K and the planning information submitted on the OPNAV 4790/2P, if the 2P has been entered into the IMMS. A simulated AWR, produced under the Shipboard Non-Tactical ADP System (SNAP), is a valid work request and will be accepted by all involved activities (see figure 2-5). An AWR may be used for any of the following purposes:

- To describe all work and planning information relating to a specific job
- To enter planning information relating to a specific job with the OPNAV 4790/2K replacing the OPNAV 4790/2P
- By an IMA to conduct advance planning of a tended unit's availability

Chapter 12 of OPNAVINST 4790.4 contains detailed information on this form.

Ship's Configuration Change Form-OPNAV 4790/CK and Ship's Configuration Change Form Continuation Page-OPNAV 4790/CK(C)

These forms shown in figures 2-6A and 2-6B are used to report configuration changes at the individual equipment level.

When you use the OPNAV 4790/CK form, you do not need to document the associated maintenance action on an OPNAV 4790/2K form. The OPNAV 4790/CK form is used both as a closing deferral for reporting the accomplishment of a previously deferred maintenance action that results in a configuration change, and as a completed maintenance action (no prior deferral) reporting a configuration change.

A configuration change occurs whenever a maintenance action results in the following situations:

- 1. Addition or installation of any new equipment.
- 2. Deletion or removal of any installed equipment.
- Replacement or exchange of any equipment. A replacement or exchange is reported as the removal of an installed equipment and installation of a new equipment.

- 4. Modification of any installed equipment. A modification results from a maintenance action that alters the design or operating characteristics of the equipment, or a maintenance action in which nonstandard replacement parts (not identified on the APL or in the technical manual) are used.
- 5. Relocation of any equipment.
- 6. Accomplishment of any alteration directive.

Two excellent documents that provide block-by-block instructions for completing the OPNAV 4790/CK are OPNAVINST 4790.4 (3-M Manual) and SPCCINST 4441.170, the *COSAL Use and Maintenance Manual*.

CURRENT SHIP'S MAINTENANCE PROJECT (CSMP)

The CSMP is an administrative system that provides the command and work center with the management data needed for the systematic accomplishment of repair and alteration of ship's hull, installed equipment, and material. It identifies at any one time the backlog of deferred maintenance for each work center. The MDS provides the means for gathering this information. If the information provided is not accurate or up-to-date or is improperly used by supervisors or maintenance technicians, the CSMP system is worthless.

The usefulness of the MDS depends upon your accuracy, thoroughness, and timeliness in reporting information. The MDS is a system in which potential benefits are directly proportional to the efforts applied. Programs for improving reliability, maintainability, and logistic support of fleet equipment depend on how conscientiously you adhere to reporting procedures.

PLANNED MAINTENANCE SYSTEM (PMS)

The Planned Maintenance System provides each command with a simple standard means for planning, scheduling, controlling, and performing planned maintenance of all equipment. PMS maintenance actions are the minimum required to maintain the equipment in a fully operable condition. Maintenance procedures are contained on cards called "maintenance requirement cards" (MRCs).

Maintenance Requirement Cards (MRCs)

The MRCs provide detailed information for performing preventive maintenance. They state exactly

SECTION I. IDENTIFICATION JOB CONTROL NUMBER 1. SHIPS #5835 3. WORK EEØ1 NUMBER 16Ø8 AEL 67382Ø134 NUMBER 16Ø8 AEL 67382Ø134 A SHIPS USS WHITE PLAINS 1. BOUID MANY COMPRESSOR MTR 1. BERNAL NO NO 2 25HP B. HULL NUMBER 14. EIC 16. LOCATION COMPARTMENT OF CK FRAME SHOE 15. SAFETY AFS-4 T5Ø5 REEFER RM 6 96 2 E							
T. SHIPS #5835 2. WORK EE # 1 1. JOB SEO 1 6 # 8 4 AFL 67382 # 134 A. SHIPS USS WHITE PLAINS 1. KOUPMENT COMPRESSOR MTR 13. IDENT/KOUIP NO 2 25HP B. HULL NUMBER 14. EIC 16. LOCATION COMPARTMENT DECK FRAME SIDE 12. SAFET B. HULL NUMBER 14. EIC 16. LOCATION COMPARTMENT DECK FRAME SIDE 12. SAFET MAZAND 14. EIC 16. LOCATION COMPARTMENT DECK FRAME SIDE 12. SAFET MAZAND 14. EIC 16. LOCATION COMPARTMENT DECK FRAME SIDE 12. SAFET MAZAND 14. EIC 16. LOCATION COMPARTMENT DECK FRAME SIDE 12. SAFET MAZAND 14. EIC 16. LOCATION COMPARTMENT DECK FRAME SIDE 12. SAFET MAZAND 14. EIC 16. LOCATION COMPARTMENT DECK FRAME SIDE 12. SAFET MAZAND 14. EIC 16. LOCATION COMPARTMENT DECK FRAME SIDE 12. SAFET MAZAND 14. EIC 16. LOCATION COMPARTMENT DECK FRAME SIDE 12. SAFET MAZAND 14. EIC 16. LOCATION COMPARTMENT DECK FRAME SIDE 12. SAFET MAZAND 14. EIC 16. LOCATION COMPARTMENT DECK FRAME SIDE 14. EIC 16. LOCATION COMPARTMENT DECK FRAME SIDE 15. SAFET MAZAND 16. LOCATION COMPARTMENT DECK FRAME SIDE 15. SAFET MAZAND 16. LOCATION COMPARTMENT DECK FRAME SIDE 15. SAFET MAZAND 16. LOCATION COMPARTMENT DECK FRAME SIDE 15. SAFET MAZAND 16. LOCATION COMPARTMENT DECK FRAME SIDE 16. LOCATION C							
A SHIP'S USS WHITE PLAINS LEQUIPMENT COMPRESSOR MTR 13 DENT/EQUIP NO.2 25HP 14 EIC 16 LOCATION COMPARTMENT DECK FRAME SHOE 13 SAFETY 14 MAZARD							
1							
1							
18. CONFIGURATION CHANGES (SHIPALTS, ORDALTS, Field ChangeLetc.) FOR INSURV BOARD USE							
19 "/" 20. INSURY NUMBER 21. SUFFIX 22. U 23. \$ [24. P							
SECTION II. DEFERRAL ACTION							
26. DEFEA. DATE 27. S.F. MHRS. 28. DEADLINE DATE 9. DEFEA							
6 8 2 2 9 8 9 6 SECTION III. COMPLETED ACTION							
28 ACT, TRN 30. BF MHRS 31. COMPLETION DATE TO STEEL STATE S							
YA DAY TIME 1 GO							
SECTION IV. REMARKS/DESCRIPTION A REMARKS NOMED MEMO INCORACE DELVE END COUND ANALYSIS DEVEATED SUADD							
OCSCRIPTION NOTED TEMP INCREASE DRIVE END. SOUND ANALISTS REVEALED SHARP							
INCREASE DB LEVELS, UNIT SECURED. S/F OPENED/INSPECTED, ROTOR SHAFT SCORED/UNDERSIZED. REMOVE MTR FRM SHIP. REPAIR SHAFT/							
BEARING SURFACE, BALANCE, ASSBL, REINSTALL, ALIGN, AND TEST.							
ST. CSMP CHARM COOPED ATMINERATION 144 SPECIAL IA. IA. IC. ID. IE. IF. IQ. IK. II. IX. IL.							
SUMMARY SHAFT SCORED/UNDERSIZED PURPOSE							
SECOND CONTACT! MAINTENANCE MAN PAYNE MM1 SECOND CONTACT! HARRIS ENC 41. PM1.1 42. T//2 43. INTEGRATED PRIORITY LE COMMANDING OFFICER'S SIGNATURE FOR THE SECOND CONTACT! LE COMMANDING OFFICER FOR THE SECOND CONTACT! LE COMMANDING OFFICER FOR THE SECOND CONTACT! LE COMMAN							
SECTION V. SUPPLEMENTARY INFORMATION							
SECTION V. SOFFEERING TO THE OWN AND THE O							
The market section							
de Répais ACTN- TIT BLURMITE PLANE TECH MANUALE TIC							
IMA LIMIT REPAIRS TO 600 \$ ROV MATERIAL.							
a manufacture IMA LIMIT REPAIRS TO 600 \$ ROV MATERIAL							
IMA LIMIT REPAIRS TO 600 \$ ROV MATERIAL							
a manufacture IMA LIMIT REPAIRS TO 600 \$ ROV MATERIAL							
SECTION VI. PLANNING							
SECTION VI. PLANNING ST. PERIODIC MAINTENANCE SECTION VI. PLANNING ST. PERIODIC MAINTENANCE SECTION VI. PLANNING ST. PERIODIC MAINTENANCE SECTION VI. PLANNING ST. PERIODIC MAINTENANCE SECTION VI. PLANNING ST. PERIODIC MAINTENANCE SECTION VI. PLANNING ST. PERIODIC MAINTENANCE SECTION VI. PLANNING ST. PERIODIC MAINTENANCE SECTION VI. PLANNING ST. PERIODIC MAINTENANCE MAINTENANCE SECTION VI. PLANNING MAINTENANCE MAINTENANC							
SECTION VI. PLANNING SI. PERIODIC MAINT REQUIRT MA. OURLAND SI. PERIODIC MAINT REQUIRT MA. OURLAND SUBSAFE M. OULLAR LEVEL 1 A. MICLEAR WORK ATVAS- A							
SECTION VI. PLANNING ST. PERIODIC MAINT RECONST. SECTION VI. PLANNING SEC							
SECTION VI. PLANNING							
SECTION VI. REPAIR ACTIVITY PLANNINGS SECTION VI. REPAIR ACTIVITY PLANNINGS SECTION VI. PAST OF STATE OF SECTION VI. REPAIR ACTIVITY PLANNINGS SECTION VI. REPAIR ACTIVITY PLANNINGS SECTION VI. REPAIR ACTIVITY PLANNINGS CHOULING ACTION							
SECTION VI. PLANNING STATE AND SECURE CONTROLS SECTION VI. PLANNING SECTION VI. PLANN							
SECTION VI. PLANNING SECTION VI. REPAIR ACTIVITY PLANNING/SCHEDULING ACTION SECTION VII. REPAIR ACTIVITY PLANNING/SCHEDULING ACTION SECTION VI. REPAIR ACTIVITY PLANNING/SCHEDULING ACTIVITY PLANNI							
SECTION VI. PLANNING ST. PERIODIC MAINT REPAIRS TO 600 \$ ROV MATERIAL SECTION VI. PLANNING ST. PERIODIC MAINT REQUINT SOLUAL S. SUBSAFE MICLEAN ROYER MICLEAN ROYER SUBMARINE ANTERNAN SUBMARINE ANTE							
SECTION VI. PLANNING STATE AND LEVEL 1 4. NON-DESTRUCT TEST 1. SUBMARIER AND TENTING 1. PET REQUIRED 1. PET R							
SECTION VI. PLANNING S. PERIODIC MANTI PEQUENT S. PERIODIC MANTI PERIODIC							
SECTION VI. PLANNING STATE AND LEVEL 1 4. NON-DESTRUCT TEST 1. SUBMARIER AND TENTING 1. PET REQUIRED 1. PET R							
SECTION VI. PLANNING ST. PERIODIC MARTI RECOMPT. SJ. PERI. SJ. YERR. SJ. SECTION VI. PLANNING SJ. SPECIAL LEVEL 1							
SECTION VI. PLANNING SECTION VI. PLANNING SECTION VI. PLANNING ST. PERIODIC MARTI PEQUANT MOUTH PEQUANT SUBSAFE INUCLEAR LEVEL 1 IN							
SECTION VI. PLANNING SI PERIODIC SECTION VI. PLANNING SI PERIODIC SI SPECIAL TESTING I MOSS CRITICAL II. DOTHER CONTROLS SURANCE I LEVEL I II. NON-DESTRUCT TEST II. SUBMARINE ANTENNAI II. SPECIAL TESTING II. MOSS CRITICAL II. DOTHER CONTROLS SURANCE II. LEVEL I II. NON-DESTRUCT TEST II. SUBMARINE ANTENNAI II. SPECIAL TESTING II. MOSS CRITICAL II. DOTHER CONTROLS SURANCE II. LEVEL I II. NON-DESTRUCT TEST II. SUBMARINE ANTENNAI II. SPECIAL TESTING II. MOSS CRITICAL II. DOTHER CONTROLS SURANCE II. REVEVENT II. SPECIAL INTEREST II. SUBMARINE ANTENNAI II. SPECIAL TESTING II. MOSS CRITICAL II. DOTHER CONTROLS SECTION VII. REPAIR ACTIVITY PLANNING/SCHEDULING ACTION START 38 A SCHED. 88 S							
SECTION VI. PLANNING SI. PERIODIC MARTI RECOMMY. SI. SECTION VI. PLANNING SI. SPECIAL DATA SI. SPECIAL CLEANING II. SPECIAL II. SPECIAL INTEREST II. SUBSANTE II. PROCEDURES SI. SPECIAL TESTING II. NON-DESTRUCT TEST II. SUBMARISHNA DI SPECIAL TESTING II. NOST-OVERHAUL SI SPECIAL INTEREST II. SUBMARISHNA DI SPECIAL TESTING II. NOST-OVERHAUL SECTION VII. REPAIR ACTIVITY PLANNINGSCHEDULING ACTION START SECTION VII. REPAIR ACTIVITY PLANNINGSCHEDULING ACTION START SI. SCHED. 18. SCH							

Figure 2-5.—OPNAV 4790/2R, Automated Work Request (AWR).

SECTIO	N I JOS IDENTIFICATION						DEFL DEFL
	J08	CONTROL NUMBE	A		ALTE	RATION IO	ENTIFICATION
	1 SHIP'S UIC	3 WOAK CENTER	3 206 840		ALTERATIONS (SHIPALT,	10 CHG . ET	(C)
A SHIP'S	HAME		10 140	LL NUMBER		5 EIC -	1 4211
7 EQUIP	MENT NOUN HAME			[4	SP WHAS EXP 0 AL	Y HAINT	10 COMP DAYE IN
	 						MAR
SECTIO		KS					
12 308 0	DESCRIPTIONMENARIS						
							
	*************************************			11			
SECTION	N III COMPONENT CONFIGURA	TION CHANGE IDE	NTIFICATION				
13 COMP	ONENT NOUN NAME						TI4 QUANTITY TIS
16 COMP	ONENT DENTFICATION	 		17 804	PONENT SERIAL NUMBER		
18. COMP	ONENT APLIAEL	110	LOCATION (DE	CK/FRAME/BIO	e)		20 EtC
	HIGHER ABBENDS Y					H IAC	25 WOAK CENTER
	PLATE DATA						23 WUMA CENTER
-							
							
ts vier	<u> </u>			30 EOE	,		
77 M	* 						
					-		
SECTION	IV SPECIAL PURPOSE						
	IV SPECIAL PURPOSE				30 SECAS OFFICE USE		
SECTION IS AIN			TP/II	PLICTIONS	<u> </u>		
	30 ALSON		SECTION 1 A	RUCTIONS	<u> </u>	LEG	NEWD
ITEM	29 ALSH		SECTION 1 A			LEG	
ITEM NUMBER 1-3	SECTION I & II SECTION I & II DESCRIPTION JOS CONTROL HAMBER ALTERATION DENTIFICATION		SECTION 1 &	ONT PAGE	<u> </u>	LEG	NEMO O OPTIONAL NA NOT REQUIRED
FTEM NUMBER	SECTION I A II SECTION I A II OESCRIPTION JOS CONTROL NUMBER	•	BECTION I A	ONT PAGE	IA FAVARABLE	LEG	O OPTIONAL
ITEM NUMBER 1-3 4	SECTION I & N SE	E	SECTION 1 A	A III CONT PAGE M IP	M FAVARABLE P FAPPLICABLE M MANDATORY		O OPTIONAL NA NOT REQUIRED
ITEM NUMBER 1-3 4 5 6 7	SECTION I & S SECTION I & S OBSCRIPTION JOS CONTROL NUMBER ALTERATION IDENTIFICATION EQUIPMENT IDENTIFICATION COO ACTION TAKEN EQUIPMENT IDENTIFICATION EQUIPMENT IDENTIFICATION EQUIPMENT IDENTIFICATION EXPERIT	NOED .	SECTION 1 A DE 1 C M M M M M M M M M M M M M M M M M M M	M IP MR NR NR	IA FAVARABLE P FAPPLICABLE	× 6	O OPTIONAL
ITEM NUMBER 1-3 4 5	SECTION I & II SECTION I & II OE SCHIPTION JOS CONTROL NUMBER ALTERATION IDENTIFICATION EQUIPMENT IDENTIFICATION ACTION TAKEN EQUIPMENT NOUN HAME	WOED .	SECTION 1 A DE 1 C M	M IP MR MR	IA F AYALABLE P F APPLICABLE M MANDATORY SECTION I, BLOC	× 6	O OPTIONAL NR NOT REQUIRED SECTION III. BLOCK 15
FTEM NUMBER 1-3 4 5 6 7 8 9 10 11	SECTION 1 & H SECTION 1 & H OESCOMPTION JOS CONTROL NUMBER ALTERATION IDENTIFICATION EQUIPMENT HOUNT NAME SHIPS FORCE MANHOURS EXPER ACTIVE MARTEMANCE TIME COMPLETION DATE METER READING	voe o	BECTION (A DE 1 C M P M M M M M M M M M M M M M M M M M	LII ONT PAGE M IP M IP M IN N N N N N N N N N N N N N N N N N	IA F AYALABLE P F APPLICABLE M MANDATORY SECTION I, BLOC	× 6	O OPTIONAL NR NOT REQUIRED SECTION III. BLOCK 15
FEM NUMBER 1-3 4 5 6 7 8 9 10 11 12	SECTION I & S DESCRIPTION JOS CONTROL MUMBER ALTERATION IDENTIFICATION EQUIPMENT IDENTIFICATION COO ACTION TAKEN EQUIPMENT INOUN NAME SHIP'S FORCE MANHOURS EXPER ACTIVE MARTEMANCE THIS COMPLETION DATE METER RELORNO JOS DESCRIPTION (REMARKS)	VOE D	BECTION I A	L II ONY PAGE M	IA F AVALABLE P F APPLICABLE MANDATORY SECTION 1, BLOC ACTION TAKES	× 6	O OPTIONAL NR NOT REQUIRED BECTION IN. BLOCK 15 COMPONENT ACTION MAINTENANCE ACTIONS R — REMOVED
FTEM NUMBER 1-3 4 5 6 7 8 9 110 111 12 ITEM NUMBER	SECTION I & S SECTION I & S OBSCRIPTION JOS CONTROL NUMBER ALTERATION IDENTIFICATION EQUIPMENT IDENTIFICATION COO ACTION TAKEN EQUIPMENT IDENTIFICATION COO ACTION TAKEN EQUIPMENT INON NAME SHIP'S FORCE MANHOURS EXPERACTIVE MANTENANCE TIME COMPLETION DATE METER RELORNO JOS DESCRIPTION (REMARKS) BECTTON IN DESCRIPTION	VOEO AEMON	BECTION I A DE I C O M M M M M M M M M M M M M M M M M M	LII ONT PAGE M IP M IP M IN N N N N N N N N N N N N N N N N N	M FAVALABLE P FAPPLICABLE M MANDATORY SECTION 1, BLOC ACTION TAKES	× 4	O OPTIONAL NR NOT REQUIRED BECTION III. BLOCK 19 COMPONENT ACTION MAINTENANCE ACTIONIS R — REMOVED EQUIPMENT 1 — RETALLED
TEM NUMBER 1-3 4 5 6 7 8 9 10 11 12 ITEM	SECTION I & I SECTION I & I OESCAPTION JOS CONTROL MANSER ALTERATION DENTIFICATION EQUIPMENT IDENTIFICATION ACTION TAKEN EQUIPMENT NOUN NAME SHIP'S FORCE MANHOURS EXPEN ACTIVE MANTENAME TIME COMPLETION DATE METER RELIDING JOS DESCRIPTION (REMARKS) SECTION III	HOED PERMON	BECTION I A DE I C M M M M M M M M M M M M M M M M M M	LEONT PAGE M IP HR	M F AVALABLE P F APPLICABLE M MANDATORY BECTION 1, BLOC ACTION TAKES M - PARTIMLY COM- ALTERATION SE - PRULY COMPLET GOVALENT TO GOVALENT TO	X 6	O OPTIONAL NR NOT REQUIRED SECTION III. BLOCK 15 COMPONENT ACTION MAINTENANCE ACTIONS R — REMOVED EQUIRMENT
TEM NUMBER 1-3 4 5 6 7 8 9 10 11 12 ITEM NUMBER 1-3 14 15 15 15 15 15 15 15 15 15 15 15 15 15	SECTION I & I DESCRIPTION JOS CONTROL NUMBER ALTERATION DENTIFICATION EQUIPMENT IDENTIFICATION COS ACTION TAKEN EQUIPMENT NOUN NAME SHIP'S FORCE MANHOURS EXPEN ACTIVE MANTENANCE TIME COMPLETION DATE METER RELIDING JOS DESCRIPTION (REMARKS) SECTION III DESCRIPTION COMPONENT NOUN NAME OUANTITY COMPONENT ACTION	PRIMOTO M	BECTON 1 1 C	LEONT PAGE M M M M M M M M M M M M M M M M M M	IA F AVALABLE P F APPLICABLE MANDATORY BECTION 1, BLOC ACTION TAKES SA - PARTIALLY COM A TERRATION A TERRATION C - POLY COMPLET GATERATION SO - A STERRATION SO - A STERRATIO	X 6 4 4 PLETED PED PED PED PED PED PED PED PED PED P	O OPTIONAL NR NOT REQUIRED SECTION IN. BLOCK 15 COMPONENT ACTION MAINTENANCE ACTIONS R — REMOVED EQUIPMENT I — HETALLID EQUIPMENT I — GOMPHIENT COMPIG PLE
FEM NUMBER 1-3 4 5 6 7 8 9 10 11 12 17 EM NUMBER 1-3 14 15 15 16 16 16 16 16 16 16 16 16 16 16 16 16	SECTION I & S DESCRIPTION JOS CONTROL NUMBER ALTERATION IDENTIFICATION EQUIPMENT IDENTIFICATION COO ACTION TAKEN EQUIPMENT IDENTIFICATION COO ACTION TAKEN EQUIPMENT IDENTIFICATION EXPER PROCE MANHOURS EXPER ACTIVE MANTEMANCE TIME COMPLETION DATE METER READING JOS DESCRIPTION (REMARKS) BECTION IN DESCRIPTION COMPORMENT NOUN NAME OUANTITY COMPORMENT ACTION COMPORMENT ACTION COMPORMENT ACTION	PE MOED REMOVE (AND) M M P	BECTON 1 C M P M M M M M P D T T T T T T T T T T T T	L E CONT PAGE M P MB MB MB MR MR MR MR MR MR MR	M. FAVALABLE P PAPLICABLE MANDATORY BECTON I, BLOC ACTION TAKES M. PARTIALLY COM ALTERATION B. FALLY COMPLET GOLVALENT TO COMPLET GOLVALENT TO OF ALTERATOR I MATERIATOR I MATERIATOR I MATERIATOR I MATERIATOR I MATERIALOR I	X 6 4 4 FED FED FED FET	O OPTIONAL NR NOT REQUIRED SECTION IN. BLOCK 15 COMPONENT ACTION MAINTENANCE ACTIONS R — REMOVED EQUIPMENT 1 — NETALLED EQUIPMENT M — MODIFED SOUPMENT COMPO FLE CORR NO MAINTENANCE
TEM NUMBER 1-3 4 5 6 7 8 9 10 11 12 ITEM NUMBER 1-3 14 15 15 15 15 15 15 15 15 15 15 15 15 15	SECTION I & I DESCRIPTION JOS CONTROL NUMBER ALTERATION DENTIFICATION EQUIPMENT IDENTIFICATION COS ACTION TAKEN EQUIPMENT NOUN NAME SHIP'S FORCE MANHOURS EXPEN ACTIVE MANTENANCE TIME COMPLETION DATE METER RELIDING JOS DESCRIPTION (REMARKS) SECTION III DESCRIPTION COMPONENT NOUN NAME OUANTITY COMPONENT ACTION	PRIMOTO M	BECTON 1 1 C	L E CONT FAGE M P MB MB NR NR NR NR NR NR NR NR NR N	M F AVAILABLE P F APPLICABLE M MANDATORY SECTION 1, BLOC ACTION TAKES ALTERATION SC — PULLY COMPLIE ALTERATION CC — PULLY COMPLIE ALTERATION ALTERATION SD — ALTERATI	X 4 V PLETED FED FECTIVE E CUTION ATS	O OPTIONAL NR NOT REQUIRED BECTION IN. BLOCK 15 COMPONENT ACTION MAINTENANCE ACTIONS R — REMOVED EQUIPMENT I — NIETALLED EQUIPMENT M — MODIFED SOUPMENT CONTO FLE COMP NO MAINTENANCE ACTION
10 An 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	SECTION I & S DESCRIPTION AS CONTROL NUMBER ALTERATION IDENTERICATION EQUIPMENT IDENTERICATION EQUIPMENT IDENTERICATION EQUIPMENT IDENTERICATION ACTION TAKEN EXPERIENCE MANHOURS EXPER ACTIVE MARTERIANCE THE COMPLETION DATE METER PRACHING JOS DESCRIPTION (REMARKS) BECTION III DESCRIPTION COMPONENT NOUN NAME OUNNITY COMPONENT FORTON COMPONENT FORTON COMPONENT SERMAL NUMBER	REMODED REMODED M M M M M M M M M M M M M	BECTON 1 C	LEONY PAGE M P NR	SA - PARTIALLY COM ALTERATION ALT	X 6 PLETED FED FED FET	O OPTIONAL NR NOT REQUIRED SECTION IN. BLOCK 15 COMPONENT ACTION MAINTENANCE ACTIONS R — REMOVED EQUIPMENT 1 — NETALLED EQUIPMENT M — MODIFED SOUPMENT COMPO FLE CORR NO MAINTENANCE
10 An 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	SECTION I & IT DESCRIPTION JOS CONTROL NUMBER ALTERATION IDENTIFICATION EQUIPMENT IDENTIFICATION COD ACTION TAKEN EQUIPMENT HOUN NAME SHIPS FORCE MANHOURS EXPER ACTIVE MANTEMANCE TIME COMPLETION OF THE JOS DESCRIPTION (REMARKS) BECTION IS BECTION IS DESCRIPTION COMPONENT NOUN NAME OUANTITY COMPONENT SERVE (CATO) COMPONENT APLAGE LOCATION EQUIPMENT IDENTIFICATION COMPONENT PLAGE LOCATION EQUIPMENT IDENTIFICATION COD	REMODED REMODED M M M M M M M M M M M M M	BECTON 1 C	LE CONT PAGE AND PAGE AND PAGE NO PAGE MARCHANT NO PAGE MARCHANT M	M. FAVALABLE P PAPLICABLE MANDATORY SECTION I, BLOC ACTION TAKES M. PARTIALLY COM ALTERATION SE - PALLY COMPLET GOLVALENT TO ALTERATION OF PALLY COMPLET GOLVALENT TO L. MANDATORY DRAWN PROM S J. MANTENANCIA COMPLETED AS COMPLETED AS COMPLETED AS MANTENANCIA COMPLETED AS MANTENANCIA COMPLETED AS MANTENANCIA COMPLETED AS MANTENANCIA MANTENANCIA	E CTION ATS	O OPTIONAL NR NOT REQUIRED SECTION IN. BLOCK 15 COMPONENT ACTION MAINTENANCE ACTIONS R — REMOVED EQUIPMENT I — NETALLID EQUIPMENT I — NOTALLID EQUIPMENT I — NOTALLID EQUIPMENT I — NOTALLID EQUIPMENT CORR HO MARTENANCE ACTION A — ADDITION OF RECORD D — GELETION OF RECORD C — CORRECTICHANGE
17 TEM TITEM TO THE TITEM TO TH	SECTION I & S DESCRIPTION AS CONTROL NUMBER ALTERATION IDENTERICATION EQUIPMENT IDENTERICATION EQUIPMENT IDENTERICATION EQUIPMENT IDENTERICATION ACTION TAKEN EXPERIENCE MANHOURS EXPER ACTIVE MARTERIANCE THE COMPLETION DATE METER PRACHING JOS DESCRIPTION (REMARKS) BECTION III DESCRIPTION COMPONENT NOUN NAME OUNNITY COMPONENT FORTON COMPONENT FORTON COMPONENT SERMAL NUMBER	PE MOED REMOVED IN PERSON IN PERSO	BECTON 1 C M P M M M M M M M M M M M	LE CONT PAGE M P M P MM NR	M. FAVALABLE P PAPPLICABLE MANDATONY BECTON I, BLOC ACTION TAKES MA - PARTIALLY COM- MITERATION SE - PALLY COMPLET GOUWALENT TO ALTERATION ON ALTERATION ON ALTERATION ON ALTERATION ON ALTERATION PARTIN PROM B J MANTENANCE A OMBUTTED AR PARTIN NOT DAA PROM B SUPPLIN IR PARTIN NOT DAA PARTIN NOT DAA PARTIN NOT DAA PARTIN NOT DAA J MANTENANCE A	ECTION ATS	O OPTIONAL NR NOT REQUIRED SECTION III, BLOCK 15 COMPONENT ACTION MAINTENANCE ACTIONS R — REMOVED EQUIPMENT 1 — NISTALLED EQUIPMENT M — NODIFIED SOUPHINT COMPILE COMPILE ACTIONS A — ADDITION OF RECORD D — DELETION OF RECORD
FEM 1-3 1-3 1-3 1-3 1-3 1-3 1-3 1-3 1-3 1-3	SECTION I & S DESCRIPTION JOS CONTROL NUMBER ALTERATION IDENTIFICATION EQUIPMENT IDENTIFICATION COD ACTION TAKEN EQUIPMENT IDENTIFICATION COD ACTION TAKEN EQUIPMENT IDENTIFICATION COD ACTION TAKEN SHIP'S FORCE MANHOURS EXPER ACTIVE MANTEMANCE THIS COMPLETION DATE METER RELORIC JOS DESCRIPTION (REMARKS) BECTION IN DESCRIPTION COMPORENT NOUN NAME OUANTITY COMPORENT ACTION COMPORENT SERVICE AND EQUIPMENT IDENTIFICATION COMPORENT ACTION COMPORENT APLASE LICCATION EQUIPMENT IDENTIFICATION COD NEXT HIGHER ASSEMBLY SERVICE APPLICATION CODE WORK CENTER	PE MAN	BECTON 1 1 C M M P M M M M M M M M M M	LEONY PAGE M P NR	M F AVAILABLE P F APPLICABLE M MANDATORY SECTION 1, BLOC ACTION TAKES A TENATION SO — PARTIALLY COMMENT A TENATION C — PARTIALLY COMMENT A TENATION SO — ALTERATION SO — ALTERATION TO — ALTERATION T	ECTION ATS	O OPTIONAL NR NOT REQUIRED SECTION IN. BLOCK 15 COMPONENT ACTION MAINTENANCE ACTIONS R — REMOVED EQUIPMENT I — NETALLID EQUIPMENT I — NOTALLID EQUIPMENT I — NOTALLID EQUIPMENT I — NOTALLID EQUIPMENT CORR HO MARTENANCE ACTION A — ADDITION OF RECORD D — GELETION OF RECORD C — CORRECTICHANGE
### ### ### ### ### ### ### ### ### ##	SECTION I & IT DESCRIPTION JOS CONTROL NUMBER ALTERATION IDENTIFICATION EQUIPMENT IDENTIFICATION COD ACTION TAKEN EQUIPMENT IDENTIFICATION COD ACTION TAKEN EQUIPMENT IDENTIFICATION EQUIPMENT IDENTIFICATION ACTIVE MAINTEMANCE TIME JOS DESCRIPTION (REMARKS) BECTION IS BECTION IS DESCRIPTION COMPONENT NOUN NAME OUANTITY COMPONENT RETAIN CATION COMPONENT RETAIN CATION EQUIPMENT IDENTIFICATION EQUIPMENT IDENTIFICATION EQUIPMENT IDENTIFICATION COD RETT HONER ASSEMBLY SERVICE APPLICATION CODE WORK CENTER NAMEPLATE DATA	PEMOLD PEMOLO PE	BECTON 1 C C	LE CONT PAGE M P P NR NR NR NR NR NR NR NR NR	M F AVAILABLE P F APPLICABLE M MANDATORY SECTION 1. BLOC ACTION TAKES ALTERATION SO - PULLY COMPLET ALTERATION C - PULLY COMPLET ALTERATION COMPLETED PA DRAWN FROM S COMPLETED PA DRAWN FROM S COMPLETED PA DRAWN ACTUBE EXPENDED SING MANTENANCE A COMPLETED NO DRAWN ACTUBE S MANTENANCE A COMPLETED NO DRAWN ACTUBE EXPENDED SING MANTENANCE A COMPLETED NO DRAWN ACTUBE EXPENDED SING MANTENANCE A COMPLETED NO DRAWN ACTUBE EXPENDED SING MANTENANCE A COMPLETED NO DRAWN ACTUBE S	ECTION ATS	O OPTIONAL NR NOT REQUIRED SECTION IN. BLOCK 15 COMPONENT ACTION MAINTENANCE ACTIONS R — REMOVED EQUIPMENT I — NETALLID EQUIPMENT I — NOTALLID EQUIPMENT I — NOTALLID EQUIPMENT I — NOTALLID EQUIPMENT CORR HO MARTENANCE ACTION A — ADDITION OF RECORD D — GELETION OF RECORD C — CORRECTICHANGE
FEM PART 1-3	SECTION I & S DESCRIPTION JOS CONTROL NUMBER ALTERATION IDENTIFICATION EQUIPMENT IDENTIFICATION COD ACTION TAKEN EQUIPMENT IDENTIFICATION COD ACTION TAKEN EQUIPMENT IDENTIFICATION COD ACTION TAKEN SHIP'S FORCE MANHOURS EXPER ACTIVE MANTEMANCE THIS COMPLETION DATE METER RELORIC JOS DESCRIPTION (REMARKS) BECTION IN DESCRIPTION COMPORENT NOUN NAME OUANTITY COMPORENT ACTION COMPORENT SERVICE AND EQUIPMENT IDENTIFICATION COMPORENT ACTION COMPORENT APLASE LICCATION EQUIPMENT IDENTIFICATION COD NEXT HIGHER ASSEMBLY SERVICE APPLICATION CODE WORK CENTER	PE MAN	BECTON 1 1 C M M P M M M M M M M M M M	LEONY PAGE M P NR	M F AVAILABLE P F APPLICABLE M MANDATORY SECTION 1. BLOC ACTION TAKES ALTERATION SO - PULLY COMPLET ALTERATION C - PULLY COMPLET ALTERATION COMPLETED PA DRAWN FROM S COMPLETED PA DRAWN FROM S COMPLETED PA DRAWN ACTUBE EXPENDED SING MANTENANCE A COMPLETED NO DRAWN ACTUBE S MANTENANCE A COMPLETED NO DRAWN ACTUBE EXPENDED SING MANTENANCE A COMPLETED NO DRAWN ACTUBE EXPENDED SING MANTENANCE A COMPLETED NO DRAWN ACTUBE EXPENDED SING MANTENANCE A COMPLETED NO DRAWN ACTUBE S	ECTION ATS	O OPTIONAL NR NOT REQUIRED SECTION IN. BLOCK 15 COMPONENT ACTION MAINTENANCE ACTIONS R — REMOVED EQUIPMENT I — NETALLID EQUIPMENT I — NOTALLID EQUIPMENT I — NOTALLID EQUIPMENT I — NOTALLID EQUIPMENT CORR HO MARTENANCE ACTION A — ADDITION OF RECORD D — GELETION OF RECORD C — CORRECTICHANGE

Figure 2-6A.—OPNAV 4790/CK, Ship's Configuration Change Form.

	URATION CHANGE FORM CONT D107-LF-047-9010		
	JOB CONTHOL NUMBER	ALTERATION IDENTIFICATION	SAME AS
HIP & UIC.	2 WORK CENTER 3 JOB SEQ NR	4 ALTERATIONS ISHIPALT, FLO CHG 41C	EXCEPT PAGE OF
	11 COMPONENT NOUN NAME		14 QUANTITY 15
	16 COMPONENT (DENTIFICATION	17 COMPONENT SERIAL NUM	nen
	18 COMPONENT APLIAGE	19 LOCATION (DECK/FRAME/SIDE)	70 E1C
	21 NEXTHIGHER ASSEMBLY		22 SAC 23 WORK CENTER
	24 NAMEPLATE DATA		
	* * * * * * * * * * * * * * * * * * *		
	<u> </u>		
			
	25 WIP	126 €OSS	
	27 TM		
			<u> </u>
		30 SECASOFFICE	USE
UP S UIC	JOB CONTROL NUMBER 2 WORK CENTER 3 JOB SEQ NR	ALTERATION IDENTIFICATION 4 ALTERATIONS (SHIPALT, FLO, CHG. ETC.)	SAME AS P1. SHI
		Table and the same	EXCEPT PAGEOF
	13 COMPONENT NOUN NAME		14 QUANTITY 15
	16 COMPONENT IDENTIFICATION	17 COMPONENT SERIAL NUM	OEP
	18 COMPONENT APL/AEL	19 LOCATION (DECK/FRAME/SIDE)	20 EIC
	21 NEXT HIGHER ASSEMBLY		22 SAC 23 WORK CENTER
	24 NAMEPLATE DATA		
			*
			*
			
	25 MIP	26 EOSE	
	27 TM		
	28 RIN 29 AILSIN	30 SECAS OFFICE	ust
	JOB CONTROL NUMBER	ALTERATION IDENTIFICATION	SAME AS
IP'S UIC	2 WORK CENTER 3 JOBSED NA	4 ALTERATIONS (SHIPALT, FLO, CHG., ETC.)	P1, SIII EXCEPT PAGE OF
	13 COMPONENT NOUN NAME		14 QUANTITY IS
	16 COMPONENT IDENTIFICATION	17 COMPONENT SERIAL NUM	I I I I I I I I I I I I I I I I I I I
	18 COMPONENT APL/AEL	19 LOCATION (DECK/FRAME/S.DE)	20 E1C
	21 NEXT HIGHER ASSEMBLY		22 SAC 23 WORK CENTER
	24 NAMEPLATE DATA		
	Za Namerica i Baria		
		<u> </u>	<u> </u>
	25 MIP	26 E038	
	27 TM		
	28 RIN 29 AILSIN	30 SECAS OFFICE	JSE
	JOB CONTROL NUMBER	ALTERATION IDENTIFICATION	SAME AS
IIP & UIC	2 WORK CENTER 3 JOBSES NR.	4. ALTERATIONS (SHIPALT, FLD, CHG. ETC.)	P1, SIII EXCEPT PAGE OF
	13 COMPONENT NOUN NAME	1	14 QUANTITY 18
	18 COMPONENT IDENTIFICATION	17 COMPONENT SERIAL NUM	DER
	18 COMPONENT APLIAEL	19 LOCATION (DECK/FRAME/BIDE)	20 EIC
	21 NEXT HIGHER ASSEMBLY		22 SAC 23 WORK CENTER
	24 NAMEPLATE DATA		
			
			
	 		<u> </u>
	25 MIP	126 8088	
	_ <u> </u>		
	27 TM	•	
			1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

Figure 2-6B.—OPNAV 4790/CK(C), Ship's Configuration Change Form Continuation Page




Figure 2-7.—Maintenance Requirement Cards

the "who, what, when, how, and with what resources" associated with a specific maintenance requirement. (See figure 2-7.)

Some MRCs have equipment guide lists (EGLs) accompanying them to serve as location guides for a number of identical equipments. A blank EGL is shown in figure 2-8.

List of Effective Pages (LOEP)

The work center LOEP contains a list of the Maintenance Index Pages (MIPs) and a brief description of the systems and equipments in the work center.

Maintenance Index Page (MIP)

A MIP contains a brief description of the maintenance requirements on all the MRCs for each item of equipment.

Schedules

Maintenance is scheduled on cycle, quarterly, and weekly schedules.

Cycle Schedule-Displays the PMS requirements to be performed during the period between major overhauls.

Quarterly Schedule-Displays each work center's PMS requirements to be performed during a specific 3-month period.

Weekly Schedule-Displays the planned maintenance scheduled for accomplishment in a work center during a specific week.

PMS Feedback Report (FBR)-OPNAV 4790/7B

The PMS feedback report, shown in figure 2-9, provides the command with an easy method of

EQUIPMENT GUIDE LIST OPNAV 4790/81 (2-76) S/N 0107-LF-047-9405	PAGE	or				
MIP NO (Less fest 2 characters)	MRC PERIODICITY					
EQUIPMENT NAME NOMENCLATURE	SERIAL NO. QUANTITY	LOCATION	APPLICABLE DATA AS REQUIRED BY MR			
			•			

Figure 2-8.—Standard Equipment Guide List (EGL).

recommending changes to maintenance requirement cards, ordering MRCs that have been lost or mutilated, and notifying the systems commands of any discrepancies in coverage.

The FBR is a five-part form composed of an original and four copies. Instructions for preparing and submitting the form are printed on the back of the last copy as illustrated in figure 2-10. You can obtain these forms through the Navy Supply System. For detailed instructions on 3-M procedures, refer to OPNAVINST 4790.4B.

THE TECHNICAL LIBRARY

Now that we have discussed the paperwork needed to complete maintenance actions, we will look at the technical library that should be setup and maintained to provide technicians the technical documents they need to perform maintenance.

In the following paragraphs we will discuss various manuals and publication that will give you a good starting point for a technical library.

PUBLICATION APPLICABILITY LISTING (PAL)

The PAL lists technical manuals, operating instruction charts, performance standards sheets, maintenance standards books, and technical manual

changes for operating and maintaining onboard systems and equipments that are under the technical cognizance of NAVSEASYSCOM.

The PAL is produced from the Ships' Technical Publications System, NAVSEA's technical manual information system, and is maintained by the Naval Ship's Data Support System (NSDSS), Port Hueneme, California. Although the PAL provides assistance in determining the publications needs of the ship or shore station to which it applies, it is not a list of required publications.

The PAL contains four separately bound volumes, each having two parts:

Volume 1–General Publications

Part 1-Electronics, HM&E, and Miscellaneous

Part 2-Weapons

Volume 1 lists only general and ship-applicable publications that do not relate to equipments or systems. It does not include any of the publications that appear in Volumes 2, 3, and 4.

• Volume 2-Electronics

Part 1-Equipment sequence

Part 2-Publication sequence

• Volume 3-HM & E

	REPORT SYMBOL OPNAV 4790-4
SEE INSTRUCTIONS OF	N BACK OF GREEN PAGE
FROM (SHIP NAME AND HULL NUMBE	2596-89
U.S.S. MIDWAY (CV-41)	DATE
NAVAL SEA SUPPORT CENTERP	ACIFIC (Category A)
TYPE COMMANDER (Category B)	
	NCE SYSTEM FEEDBACK REPORT
SYSTEM, SUB-SYSTEM, OR COMPONENT	APL/CID/AN NO./MK. MOD.
SYSCOM MIP CONTROL NUMBER	SYSCOM MRC CONTROL NUMBER
DESCRIPTION	N OF PROBLEM
CATEGORY A	CATEGORY B
XX MIP/MRC REPLACEMENT	TECHNICAL
	TYCOM ASSISTANCE
	OTHER (Specify)
MIPs only, A-33/109 EL-11/12	-87
	IRCs 18 2 each 1 each
MRCs only, (MIP E-1	5 each 4/749-22) 69 T965 S
DEPT HEAD FROM ENTER CODE	3-M COORDINATORY
Originator do not write be	low, For TYCOM ese only.
TYCOM CONCUR DO NOT	
TYCOM REP SIGNATURE	DATE
S/N 0107-LF-007-8000	N COPY PAGE OF
EDITION OF 3-84 MAY	BE USED UNTIL EXHAUSTED

Figure 2-9.—OPNAV 4790/7B, PMS Feedback Report (FBR).

Part 1-Equipment sequence

Part 2-Publication sequence

● Volume 4–Weapons

Part 1-Equipment sequence

Part 2-Publication sequence

MAINTENANCE STANDARDS HANDBOOKS

Maintenance standards handbooks describe a series of specially developed preventive maintenance procedures that, when performed as directed, will reveal areas of subnormal performance and provide for

1. ORIGINATOR:

- Typewritten copies are preferred, however handprinted copies are acceptable. Use ballpoint pen and ensure all copies are legible.
- b. EQUIPMENT IDENTIFICATION: Fill in titled blocks that apply. Give as much information that can be determined. Ensure that currect APL number is used for hull, mechanical or electrical equipment or electronic/weapons equipment which does not have an Army-Navy number or mark/mod designation.
- c. DESCRIPTION OF PROBLEM: Check the appropriate box.

Category A

(1) MIP/MRC REPLACEMENT: Ensure that PMS documentation request is current in accordance with latest SFR. For missing MIP's/MRC's, give SYS-COM control numbers when they can be determined. If SYSCOM control numbers cannot be determined, provide as much nameplate data as can be obtained. When ordering a variety of missing/worn MIP's/MRC's, the subject section shall be left blank.

Category B

- (2) TECHNICAL: (a) Identify specific discrepancy discovered in PMS by MRC control number, step number, etc.
 - (b) For publication discrepancies identify publication by number, volume, revision date/number, change number, page, paragraph and or figure as appropriate.

THIS FORM WILL NOT BE USED TO ORDER PUBLICATIONS.

- (3) TYCOM ASSISTANCE: Includes clarification of 3-M instructions and other matters related to PMS administration.
- (4) OTHER: Identify in detail any problem not covered by (1) through (3) above. Shifts of maintenance responsibility will be reported under this item. Ensure that all work centers involved in the change are identified by work center code. Approval by the Executive Officer will be shown in the "Remarks".
- d. REMARKS: Provide brief, but complete, description of problem or requirement. Executive Officer institute approval of maintenance responsibility shift by endorsement. Use additional forms if more space is required. Mark additional forms, "page 2 of 2", "page 2 of 3", etc. Staple additional forms behind basic form.
- ORIGINATOR IDENTIFICATION: Sign and insert work center code in appropriate space.
- DIVISION OFFICER: Review for accuracy and completeness and sign in the space provided.
- 3. DEPARTMENT HEAD: Review for accuracy and completeness and sign in the space provided.
- 4. 3-M COORDINATOR:
 - a. Serialize, date and sign in the appropriate spaces.
 - b. Routing Instructions: For category "A" FBR's forward the white and yellow copies to the appropriate NAVSEACEN and the pink copy to the TYCOM. For category "B" FBR's forward the white, yellow and pink copies to the TYCOM. Retain blue copy in suspense file. Return green copy to the originator.

OPNAV 4790/78 (Back)

Figure 2-10.—Instructions for Preparing the PMS Feedback Report (reverse side of FBR form).

effective mechanical and electrical maintenance of the equipment. The installing activity performs those procedures on the equipment when it is operating properly and publishes the results as "designated reference standards." The designated reference standards collectively represent normal performance. This allows you to compare the results of a scheduled

test with the reference standards to identify, properly analyze, and correct abnormalities.

NAVAL SHIPS' TECHNICAL MANUAL (NSTM)

The NSTM is a set of books (chapters) that contain general information on a variety of topics. You can find

a complete listing of the NSTM chapters in chapter 001, *General - NSTM Publications Index and User Guide.* The chapters we have listed below are related to your job, both as a technician and as a member of a ship's or station's organization.

NSTM Chapter 79-Practical Damage Control (DC)

This chapter provides broad guidance for establishing a DC organization. This guidance is designed to help organizations plan before damage occurs, spend a minimal amount of time localizing damage that does occur, and make emergency repairs or restoration as quickly as possible after damage occurs.

NSTM Chapter 300-Electrical Plant

This chapter provides information and instructions on electrical equipment, electrical safety precautions, electrical insulation and insulation resistance, and maintenance reconditioning of electrical equipment. It provides the requirements we, as ETs, must meet in a shipboard safety program, including use and maintenance of organizational electrical and electronic equipment and personal electrical and electronic equipment.

NSTM Chapter 400-Electronics

This chapter provides major policies and instructions pertaining to maintenance of electronic equipment and safety information aboard active and reserve ships.

NSTM Chapter 631-Preservation of Ships in Service

This chapter provides instructions, requirements, and information for prevention of corrosion of ships, boats, and small craft. Topics include surface preparation, painting, and application of other preventive measures.

NSTM Chapter 634-Deck Coverings

This chapter provides information concerning materials, installation procedures, maintenance and repair of deck coverings, gratings, sealing methods, and caulking compounds used for sealing deck seams.



ELECTRONICS INSTALLATION AND MAINTENANCE BOOK (EIMB)

The EIMB is the medium for collecting, publishing, and distributing, in one convenient source, safety information, maintenance policies and philosophies, installation standards and practices, and overall electronic equipment and material-handling procedures required by Chapter 400 of the *Naval Ships' Technical Manual*. The EIMB is organized into a 13-volume series of individual books.

EIMB General Handbook

This handbook provides data pertaining to administration, supply, publications, and safety matters, and contains the subject index for information contained in the other handbooks.

EIMB Installation Standards Handbook

This handbook issues approved standards, techniques, and practices for the installation of electronic equipment aboard ships.

EIMB Electronic Circuits Handbook

This handbook provides the theory of operation and circuit description of basic vacuum tube and semiconductor circuits.

EIMB Test Methods and Practices Handbook

This handbook provides technicians with reference information on the fundamentals of test methods and basic measurements, step-by-step procedures for testing typical electronic circuits and equipment, and fictional descriptions of the theory of operation of the test equipment used and circuits tested.

EIMB Reference Data Handbook

This handbook contains an encyclopedic presentation of useful and informative definitions,

abbreviations, formulas, and other general data related to electronics installations and maintenance.

EIMB EMI Reduction Handbook

This handbook contains techniques and procedures for the elimination or reduction of electromagnetic interference created by own force's electromagnetic radiating devices.

EIMB General Maintenance Handbook

This handbook contains routine maintenance concepts, techniques, and procedures common to all electronic and electrical equipment.

EIMB Equipment-Oriented Handbooks

For the basic equipment category, each of the six handbooks contains general servicing information; servicing information for specific equipments; a field change identification guide that provides field change information for all equipments of the basic equipment category; and functional descriptions common to the equipment of the basic equipment category. The six equipment-oriented handbooks are as follows:

- 1. Communications
- 2. Radar
- 3. Sonar
- 4. Test Equipment
- 5. Radiac
- 6. Countermeasures

Periodically, the equipment-oriented handbooks are updated by incorporating the *Engineening Information Bulletin* (EIB) articles. The EIMBs are an excellent source of basic information that can be used as a training tool for your workcenter. If space is available, you will benefit from having a complete set for your technical library.

OTHER PUBLICATIONS

There are many other useful publications throughout the fleet. However, because of the vast number, we will only describe a few in the following paragraphs.

Shipboard Antenna Systems Manuals

These five manuals serve as a source of information for personnel concerned with the installation and maintenance of shipboard antennas. The information they contain supplements, but does not supersede, existing specifications. The following is a list of what each volume contains:

- Volume 1-Communications Antenna Fundamentals
- Volume 2-Installation Details, Communications Antenna Systems
- Volume 3-Antenna Couplers, Communications Antenna Systems
- Volume 4–Testing and Maintenance, Communications Antenna Systems
- Volume 5-Antenna Data Sheets

Miniature/Microminiature (2M) Electronic Repair Program

While this publication (three volumes under one cover) gives procedures and techniques, personnel must be formally trained and certified to make high-quality, reliable repairs to state-of-the-art electronic printed circuits and modules.

Shipboard Bonding, Grounding, and Other Techniques for Electromagnetic Compatibility and Safety, Military Standard 1310 (NAVY)

The requirements of this standard apply to all new shipboard installations and to any part of an existing installation that is being modified. The procedures and methods specified in this standard apply to any situation that requires the technician to (1) bond, ground, insulate, or use nonmetallic materials to provide electromagnetic compatibility; (2) provide personnel safety from electrical shock hazards; (3) safeguard electrical transmissions of classified information; and (4) provide a dc reference ground. We recommend this publication as a MUST reading assignment for all Electronics Technicians.

Electromagnetic Radiation Hazards (Hazards to Personnel, Fuel, and Other Flammable Material)

This manual prescribes operating procedures and precautions to prevent injury to personnel, ignition of

volatile vapors, and premature initiation of electroexplosive devices in ordnance caused by exposure to environmental electromagnetic radiation.

Data in this manual are provided in two volumes as follows:

Volume I

Hazards to Personnel, Fuel, and Other Flammable Material (U)

Volume II

Part I-Hazards to Unclassified Ordnance Systems (U)

Part II-Hazards to Classified Ordnance Systems (U)

Volume I and Volume II, Part One, are unclassified All classified data are contained in Volume II. Part Two.

Installation Criteria for Shipboard Secure Electrical Information Processing Systems, Military Standard 1680 (SHIPS)

This standard sets forth the design and installation criteria that apply to shipboard secure electrical information processing systems, including detailed hardware and equipment requirements and the applicable inspection and reporting procedures and documentation. Installation and maintenance technicians of these processing systems MUST be well versed in the contents of this standard.

General-Purpose Electronic Test Equipment, Military Standard 1364 (Series) (NAVY)

This standard identifies standard General-purpose Electronic Test Equipment (GPETE), GPETE support items, and General Use Portable Electrical Equipment (GUPEE) that are suitable for Navy use and for which the Naval Sea Systems Command exercises material support responsibility by management of item entry. This standard also establishes uniform procedures for submission of applications to procure nonstandard GPETE.

Military Specification Manuals, Technical: Functionally Oriented Maintenance Manuals (FOMM) for Electronic, Electromechanical, and Ordnance Equipment Systems, and Platforms, Military Specification Mil-M-24100C

This specification sets forth the content and format requirements for FOMMS, and their revisions and changes, necessary for the installation operation, repair (organizational-level, intermediate-level, and depot-level), and parts support of equipment, systems, and subsystems without the services of manufacturer's representatives.

Procedures for Conducting a Shipboard Electromagnetic Interference (EMI) Survey (Surface Ships), Military Standard 1605 (SHIPS)

This standard provides detailed procedures for conducting an electromagnetic interference survey aboard surface ships.

Navy Electricity and Electronics Training Series (NEETS)

At present there are 24 NEETS modules. These modules contain a vast amount of information from an introduction to matter, energy, and direct current to an introduction to fiber optics.

The NEETS modules are high quality training aids as well as excellent review publications for basic electronics for all ETs.

CATALOGS, LISTS, INDEXES, AND DIRECTORIES

The following paragraphs will discuss catalogs, lists, indexes and directories of electronic equipment.

Equipment Identification Code (EIC) Master Index

This index provides a listing of equipment identification codes (EICs) in two sections. Section I lists EIC numbers in numerical sequence and identifies the equipment nomenclature assigned to each EIC number. Section II is the complement of Section I. It lists nomenclature in alphanumerical sequence and identifies the EIC numbers assigned to equipment.

Guide for User Maintenance of NAVSEA Technical Manuals

The maintenance of up-to-date technical manuals aboard your command is essential to the operational readiness of the command systems and equipment. This guide will bean important part of the technical library.

Electrostatic Discharge Control Handbook for Protection of Electrical and Electronic Parts, Assemblies and Equipment (Excluding electrically initiated explosive devices) (METRIC), Military Handbook 263A

This handbook provides guidance, not requirements, for the establishment and implementation

of an Electrostatic Discharge (ESD) Control Program according to the requirements of MIL-STD-1686. This document applies to the protection of electrical and electronic parts, assemblies and equipment from damage due to ESD. It does not provide information for the protection of electrically initiated explosive devices.

Metrology Automated System for Uniform Recall and Reporting (MEASURE) User's Manual

This manual outlines the procedures that apply to Navy calibration facilities using the system, ship and shore activities obtaining services from them, and other military activities whose use of MEASURE is in effect.